

## REED WAX RECIPE

4 oz. refined beeswax  
1 oz. paraffin  
1 oz. white pine rosin, refined, cooled  
7/8 tsp. raw linseed oil

### Directions:

Assemble aluminum pie tins, one per 'batch' of wax.  
Coat the inside generously with vegetable oil. Set aside.

Melt all ingredients together in an pan over a low flame on the stove,  
stirring occasionally; watch closely.

When all the ingredients are liquefied, pour the into aluminum pie  
tins. Let cool.

The wax will harden as it cools, and will become a lighter color. It  
may be used as soon as it is cool and is hardened enough to handle.  
Score with utility knife (box cutter or exacto) into half inch  
strips and store in a zip locked baggie.

Happy waxing!

Accordion to Pete.